


PRINT OF DRAWINGS



F16. 2 Program Guide Chennel (Prior Ait)






FIG. 3 User-Interface unit for an Interactive Electronic Program Guide, (Prior Art)



PRINT OF DRAWINGS
AS ORIGINALLY FILED





•		
611	channel number	•
612	+i+le	
613	first time slot	01
614	start offset	
615	length	٠
616	end offset	
617	category	
-		

FIG. 6A Program-Guide Database

63 SLE Surf Reeft enable
64 SLN Surf left chemnel no.
65 SRE Surf right enable
66 SRN Surf right channel no.
67 NCN Next Category channel no.
68 PCN Previous Category Chemnel no.


F16.66 Variables Maintained by Electronic Program Guide to Support Sicleways Surfers

AS ORIGINALLY FILED

category 624 selected channel Series (Comedy) number I Love Lucy 132 +itle 623 621 indication of Program (5) in category of program on selected channel at higher num beved channels (present) indication of program (s) In Category of program selected channel at lower

FIG. 6B Channel Hat

numbered channels (absent)







FIG. 8 Flow Chart of Algorithm used in Selecting Channels and Surfing in TV mode.






FIG. 9B Steps Added to Algorithm 90 to Prepare for Surfing to a Channel Carrying a Program in the Previous Category